

Fig.-1A  **PRIOR-ART**




Fig.-~3




Fig. ~5




Fig. -7




Fig.-8




Fig.-6




Fig -9

SHOWER HEAD SOAP DISPENSER

00000000000000000000000000000000




Fig. 2

Digitized by Srinivasulu





Fig. 10B

Fig. 10C







Fig. 11A

099212560
"ON"
PUMP
HOUSING



WHEN SPRING BOUNCE BACK, THE VALVE WILL CLOSE & DON'T LET THE SOAP GO BACK TO REAR OF PUMP HOUSING. IT WILL ALSO PUSH THE SOAP, IN FRONT OF PUMP HOUSING, OUT THROUGH OUTLET TO SHOWER HEAD OR DOWNWARD.

Fig. 11B

DOVER CO. INC. 1560




Fig. 12




Fig. 13A

0992550 - 02604




Fig. 13B